

NOMAD ASSEMBLY INSTRUCTIONS

These instructions are to assist you to assemble your computer cart for your Nomad System.



The following items are need to assemble the computer cart:

A) Computer Cart - with manufacturers assembly instructions.

Assemble with one tray facing forward as high as possible, and one tray facing backwards as low as possible.



C) Table and support for keyboard and mouse tray

1 ABS plastic table with rounded top bolts.

1 ABS plastic support with preinstalled metal brackets

The table will attach above the computer cart tray, with the support attaching below. This will serve as a keyboard and mouse. Refer to picture below of completely assembled system.



Installation Instructions:

OVERVIEW: The computer cart, when fully assembled, should look like the picture to the right.

Note: The Nomad cart will be assembled slightly different to what is shown in the manufacturer's instructions included with the computer cart packaging.

These instructions will explain these differences.



STEP 1 : Assemble cart following the manufacturer's instructions.

Follow the manufacturer's instructions on installing your TV to the cart.

There will be two metal trays included in your TV Cart box. One should be installed pointing away from the front of the cart as low as possible. This will be the tray that supports the computer.



STEP 2 : Install computer to bottom rear facing tray.

The computer will sit on top of the bottom, rear facing tray.

Use the buckled strap to secure the computer and tray upright against the frame of the TV cart




Step 4 : Install Keyboard table

Unscrew and remove any nuts or washers that were attached for shipping

Place the keyboard tray with carriage bolts onto the front facing tray, making sure the carriage bolts run through the slots in the tray.



Lift the bottom supporting bracket to the middle three carriage bolts.



Secure the bottom supporting bracket with 3 washers and 3 nuts, one per carriage bolt



Secure the remaining 4 carriage bolts to the metal tray with 4 washers and wing nuts.

